


Driver's Dashboard Panel Removal and Installation

Removal/Installation

1. Driver's Dashboard Lower Cover - Remove
2. Driver's Outer Dashboard Trim - Remove
3. Dashboard Meter Visor - Remove (as needed)
4. Driver's Dashboard Panel - Remove

Fastener Locations

▷ : 5



1. Remove the driver's dashboard panel (A).
2. For some models: Disconnect the connectors (B).

5. All Removed Parts - Install

1. Install the parts in the reverse order of removal.

